



Diagnostic Trouble Code (DTC) Indication

1. Connect the SCS service connector to the service check connector under the glove box.




2. Turn the ignition switch ON (II), but do not start the engine.
3. Record the blinking frequency of the ABS indicator light. The blinking frequency indicates the diagnostic trouble code (DTC).

NOTE: Check the DTC carefully and record it. The memory of the DTC is erased if the connector is disconnected from the ABS control unit.



DTC Indication Pattern (When the ABS control unit detected a problem three times.):



- Turn the ignition switch ON (II). The ABS indicator light comes on for two seconds to check the bulb.
- The ABS control unit indicates the DTC three times.
- If you miscount the blinking frequency or if you recheck the blinking frequency, turn the ignition switch OFF then turn it ON (II) to cycle the ABS indicator light again.

4. Remove the SCS service connector.

NOTE: The Malfunction Indicator Lamp (MIL) will stay on after the engine is started if the SCS service connector is connected.

5. Remove the ABS B2 (15 A) fuse in the under-hood fuse/relay box for at least three seconds to erase the ABS control unit's memory.