### **MACURA**

## **INSTALLATION INSTRUCTIONS**

Accessory

FRONT UNDER SPOILER

Application

2003 3.2TL

BII 23709

Publications No.

Issue Date **MAR 2002** 

# **PARTS LIST** Front under spoiler 6 Flange bolts 3 Bumper bolts 9 Flange nuts 2 Short self-tapping screws

### **TOOLS AND SUPPLIES REQUIRED**

Ratchet

2 Collars

10 mm Socket

4 Spring nuts

#2 Phillips screwdriver

2 Long self-tapping screws

Shop towel

Drill

3 mm and 10 mm Drill bits

Center punch

File

Ispropyl alcohol

Blanket

Eye protection (face shield, safety goggles, etc.)

### **INSTALLATION**

Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your car. These procedures should not be attempted by "do-it-yourselfers."

NOTE: A nose mask cannot be used with the front under spoiler. If equipped, remove the nose mask.

Open the hood. Remove the front bulkhead cover (10 clips).

