




## Pump Overhaul

### Exploded View

Replace the pump as an assembly if the parts indicated with an asterisk (\*) are worn or damaged.



(cont'd)