





- A/T Gear Position Indicator
- Audio Unit/Audio-Navigation Unit
- Telematics Control Unit/HandsFreeLink Control Unit
- Center Switch Panel/Interface Dial
- Center Display Unit
- Console Accessory Power Socket Relay

- AWD Control Unit
- Engine Mount Control Unit
- Keyless Access/TPMS Control Unit
- Gauge Control Module
- Data Link Connector (DLC)
- SRS Unit
- Steering Angle Sensor
- Audio Unit/Audio-Navigation Unit
- ANC/Active Sound Control Unit
- Front Camera
- EPS Control Unit
- VSA Modulator-Control Unit
- PCM

- Windshield Washer Main Relay
- Starter Cut Relay 1
- MAF Sensor/IAT Sensor
- ELD
- Starter Cut Relay 1
- Brake Light Relay
- Brake Pedal Position Switch
- PCM
- EVAP Canister Purge Valve
- Under-Dash Fuse/Relay Box

- 7.PUR
- 2.WHT
- 7.BLK
- 2.PUR
- 3.WHT
- 8.RED
- 12.GRY
- 10.LT.BLU
- 15.LT.BLU
- 3.LT.BLU
- 10.PUR
- 1.YEL
- 15.0RN
- 20.0RN
- 3.TAN
- 6.0RED
- 1.RED
- 32.BLU









