

Maintenance Minders™

Acura's equipped with Maintenance Minder™ measures driving style, road conditions, and helps to notify you when scheduled maintenance is due. When you see the wrench, it's time for Acura Genuine Service.

Maintenance Schedule

The Maintenance Schedule calculates service needs based on your car's mileage. It checks engine-operating conditions and helps coordinate oil service dates and other maintenance check-ups. Prevent problems before they occur.

Maintenance Minder A

6 SPEED AUTOMATIC AWD WITH TECHNOLOGY AND ACURAWATCH PLUS PACKAGES - Recommended service:

- Replace engine oil*¹
- *1: If the message SERVICE does not appear more than 12 months after the display is reset, change the engine oil every year.
- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

Maintenance Minder B

6 SPEED AUTOMATIC AWD WITH TECHNOLOGY AND ACURAWATCH PLUS PACKAGES - Recommended service:

- Replace engine oil*¹ and oil filter
- Inspect front and rear brakes, service as necessary
- Check parking brake adjustment
- Inspect tie rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots
- Inspect brake hoses and lines (including ABS/VSA)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- *1: If the message SERVICE does not appear more than 12 months after the display is reset, change the engine oil every year.
- #: See information on maintenance and emissions warranty of your [owner's manual \(/vehicles/information/2016/RDX/manuals\)](#).
- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

Maintenance Minder 1

6 SPEED AUTOMATIC AWD WITH TECHNOLOGY AND ACURAWATCH PLUS PACKAGES - Recommended service:

- Rotate tires
- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

Maintenance Minder 2

6 SPEED AUTOMATIC AWD WITH TECHNOLOGY AND ACURAWATCH PLUS PACKAGES - Recommended service:

- Replace air cleaner element*²
- Replace dust and pollen filter*³
- Inspect drive belt
- *2: If you drive in dusty conditions, replace the air cleaner element every 15,000 miles (24,000 km).
- *3: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 15,000 miles (24,000 km).
- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

Maintenance Minder 3

6 SPEED AUTOMATIC AWD WITH TECHNOLOGY AND ACURAWATCH PLUS PACKAGES - Recommended service:

- Replace transmission and transfer fluid*
- * Not available on all models
- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

Maintenance Minder 4

6 SPEED AUTOMATIC AWD WITH TECHNOLOGY AND ACURAWATCH PLUS PACKAGES - Recommended service:

- Replace spark plugs
- Replace timing belt and inspect water pump*⁴
- Inspect valve clearance
- *4: If you drive regularly in very high temperatures (over 110°F, 43°C), in very low temperatures (under -20°F, -29°C), or tow a trailer, replace every 60,000 miles/100,000 km.
- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

Inspect the valves during services A, B, 1, 2, or 3 if they are noisy.

Maintenance Minder 5

6 SPEED AUTOMATIC AWD WITH TECHNOLOGY AND ACURAWATCH PLUS PACKAGES - Recommended service:

- Replace engine coolant
- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

Maintenance Minder 6

6 SPEED AUTOMATIC AWD WITH TECHNOLOGY AND ACURAWATCH PLUS PACKAGES - Recommended service:

- Replace rear differential fluid*
- * Not available on all models
- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.