
REMOVAL & INSTALLATION > MIRROR HOUSING COVER REMOVAL AND INSTALLATION (2013-18) > REMOVAL

- 1. Side Turn Signal Light Remove
 - 1. Remove the side turn signal light .
- 2. Mirror Housing Remove




1. Release the hooks (A, B), then remove the visor (C) and the mirror housing (D).

REMOVAL & INSTALLATION > MIRROR HOUSING COVER REMOVAL AND INSTALLATION (2013-18) > INSTALLATION

1. Mirror Housing - Install


1. Install the visor (A) and the mirror housing (B).




REMOVAL & INSTALLATION > POWER MIRROR REMOVAL AND INSTALLATION (2013-18) > REMOVAL

- 1. Front Door Panel Remove
 - 1. Remove the front door panel Refer to: Front Door Panel Removal and Installation (2013-18), or Front Door Panel Removal and Installation(With BSI Alert Indicator) (2016-18).
- 2. Power Mirror Remove

ct the power mirror connector (A) he harness clip (B).		




Courtesy of HONDA, U.S.A., INC.



Courtesy of HONDA, U.S.A., INC.

- 3. Remove the plug caps (A)
- 4. While holding the power mirror (B), remove the nuts (C).


5. Remove the power mirror (A).



Courtesy of HONDA, U.S.A., INC.


REMOVAL & INSTALLATION > POWER MIRROR REMOVAL AND INSTALLATION (2013-18) > INSTALLATION

1. Power Mirror - Install




Courtesy of HONDA, U.S.A., INC.

1. Install the power mirror (A).



Courtesy of HONDA, U.S.A., INC.

- 2. While holding the power mirror (A), install the nuts (B)
- 3. Install the plug caps (C).



Courtesy of HONDA, U.S.A., INC.

- 4. Install the harness clip (A)
- **B** 5. Connect the power mirror connector (B).

2. Front Door Panel - Install

1. Install the front door panel - Refer to: Front Door Panel Removal and Installation (2013-18), or Front Door Panel Removal and Installation(With BSI Alert Indicator) (2016-18).