

Power Windows

Resetting the Power Window Control Unit (cont'd)

Front Passenger's Power Window

9. Move the front passenger's window all the way down using the front passenger's power window DOWN switch.
10. Pull up and hold the front passenger's power window UP switch until the front passenger's window is all the way up, then continue to hold the switch for several seconds.
11. Confirm that the power window control unit is reset by using the front passenger's power window AUTO UP and DOWN functions.

