




Pump Overhaul

Exploded View

Replace the pump as an assembly if the parts indicated with an asterisk (*) are worn or damaged.



(cont'd)