

■ Key Information

Do the following before starting your work.

Remove:

- [Cargo Bin Cap](#)

■ Sub-Procedure

● Removal

1. While pushing down on the seat cushion (a), pull the seat hook handles (b) to release the hooks (c).
2. Pull back the seat cushion to pull off the seat belt buckles (d) from the slits in the seat cushion, and remove it.

