

## Engine Oil Level Check

**Check**

[How to use this manual.](#)

### 1. Engine Oil Level - Check

#### ■ Preconditions

- Vehicle on Level Ground
- Engine Warmed Up


---

#### ■ Procedure/Specifications

1. Turn the engine off after warming it up and wait 3 minutes.
2. Remove the dipstick, and wipe off the dipstick, then reinstall the dipstick.
3. Remove the dipstick, and check the oil level.

#### Normal Conditions

Position	Specifications
A: Upper Mark	Engine oil level should be between A and B
B: Lower Mark	



---

## ■ Result

- If the oil level is near or below the lower mark, check for oil leaks, and [add oil](#) to bring it to the upper mark.