

Acura : TL : 2004-08

Front : Left

Actual	Before	Specified Range
-0.8°	-0.7°	-1.0° 0.0°
2.8°	2.8°	2.5° 4.0°
-0.04°	-0.08°	-0.08° 0.08°
10.3°	10.3°	
9.6°	9.6°	

Camber
Caster
Toe
SAI
Included Angle
Turning Angle Diff.

Front : Right

Actual	Before	Specified Range
-0.7°	-0.8°	-1.0° 0.0°
2.7°	2.7°	2.5° 4.0°
0.00°	-0.04°	-0.08° 0.08°
10.3°	10.3°	
9.5°	9.5°	

Front

Cross Camber
Cross Caster
Cross SAI
Total Toe
Cross Turn Diff.

Actual	Before	Specified Range
0.0°	0.1°	-0.8° 0.8°
0.1°	0.1°	-0.8° 0.8°
0.1°	0.0°	
-0.04°	-0.12°	-0.16° 0.16°

Rear : Left

Actual	Before	Specified Range
-1.5°*	-1.5°	-1.5° -0.5°
0.04°	0.01°	-0.08° 0.08°

Camber
Toe

Rear : Right

Actual	Before	Specified Range
-1.3°	-1.3°	-1.5° -0.5°
0.01°	-0.13°*	-0.08° 0.08°

Rear

Cross Camber
Total Toe
Thrust Angle

Actual	Before	Specified Range
-0.3°	-0.2°	-0.8° 0.8°
0.05°	-0.13°	-0.16° 0.16°
0.01°	0.07°	

* This value is not within specification. Tire wear, handling and safety problems may result.