

## 2010 Acura TL


Submodel: SH-AWD | Engine Type: V6 | Liters: 3.7

Fuel Delivery: FI | Fuel: GAS

---

1. Open the center console lid.
2. Carefully pry out the console box light out of the center console.
3. Twist the socket (A) to remove it from the console box light (B).

**Console  
Box Light:** 1.4 W



4. Remove the bulb (C) from the socket.
5. Install the light in the reverse order of removal.